

Packaging Steps For High Power Lithium Batteries

How to safely stack lithium batteries in the ULiB™ Box



Remove bag of CellblockEX Fire Suppressant from the ULiB Box





Step 2 Place Lithium Battery into ULiB Box





Place CellblockEX Bag on top of the battery and partially close the lid

Note: In the event of a battery fire the heat will release the CellblockEX granules from the bag and extinguish the battery fire.





Continue to load batteries into the ULiB Box as they become available, with a minimum 25-30mm spacing between each battery.





After each additional battery is stacked in the ULiB Box return the CellblockEX Bag on top and partially close the lid





When the ULiB Box is full cut the top of the CellblockEx bag and pour the granules into the ULiB Box





Make sure that the batteries are covered with at least 25-30mm of CellblockEX granules





Close the ULiB Box and secure with the 2 over-center Snap-Flat latches.

Goto the UNISEG website, for DG Label Templates to attach to the front and rear of the box.

